


Support Center > Hardware Support > Card Readers

Connecting the B200 and B250 to your mobile device

See below for how to connect your B200 or B250 bluetooth card reader to your mobile device and begin taking payments with SwipeSimple.



Directions

- 1. Charge your card reader with the enclosed USB cable. You can either connect the card reader to a computer or power adapter. A full charge may take up to two hours.
- 2. Download and install the SwipeSimple app. The app can be downloaded from the App store or Google Play Store.
- 3. Enable Bluetooth on your device
- 4. Press and hold the power button on the reader until a light starts flashing blue
- 5. Enter the SwipeSimple application. Type in an amount, then tap on **Checkout**

6. Agree or Ok to all permissions asked by your device

- 7. Tap on Select Reader, a white box will pop up with the Reader name to select
- 8. Then you will see "Connected"

Having trouble connecting your device? Follow these troubleshooting steps:

iOS

- 1. Ensure that reader is on and fully charged
- 2. Ensure reader is not paired in Bluetooth settings
- 3. Ensure that permissions are enabled for SwipeSimple
 - 1. Open device Settings
 - 2. Scroll down to the bottom, where the apps on the device are listed, select SwipeSimple
 - 3. Ensure that Bluetooth, Microphone, and Local Network is enabled for SwipeSimple

If reader still does not appear during transaction, try resetting with a paperclip

Android

- 1. Ensure that reader is on and fully charged
- 2. Ensure that permissions are enabled for SwipeSimple
 - 1. Open device Settings
 - 2. Go to Apps and select SwipeSimple
 - 3. Go to Permissions
 - 1. Ensure that all permissions are enabled (likely Location, Microphone, Storage, and Camera)
- 3. If reader still does not appear as option during transaction, try enabling the location on the device
 - 1. Open device settings and go to Location
 - 2. If OFF, toggle ON
 - 3. If ON, toggle OFF, then back ON

If reader still does not appear as option during transaction, try resetting with a paperclip

Note: it may be helpful to un-pair the reader in the Android Bluetooth settings after this reset

Other important notes:

The B200 and B250 Bluetooth readers can only be paired to one device at a time. Ensure the Bluetooth reader is not paired with another device. If the reader is paired to another device, please select "Forget This Device" in the Bluetooth settings and try again.



21 out of 21 found this helpful

Articles in this section

- Card Reader Firmware Update
- Swift B200 and B250: Compatible devices
- Device Management
- Can I buy a countertop cradle or charging stand for my card reader?
- A200: Compatible Devices and Connectivity
- Connecting the B200 and B250 to your mobile device
- B250 charging stand

Solutions	Products	Business Types	Company	Resources
Card readers	SwipeSimple Payments	Food and beverage	About us	Contact us
Invoices	SwipeSimple Terminal	Retail	Become a partner	Content Hub
Mobile App	SwipeSimple Register	In-person services	Safety and security	Support Center
Payment Links		On-site services		
Reporting Dashboard				

©2023 CardFlight. All rights reserved.

Terms and Conditions Privacy Policy CCPA Notice